## 9025-XP RAM Front Panel Layout



## Description:

The 9025-XP front panel layout shows O2 and CO values, alarm/low battery indications, air flow, and provides access to the zero button and calibration port. To zero the readings (in clean air) press and relese the zero button. To calibrate with gas, attach calibration gas to the "cal port" and follow the cal instructions. Adjust the flow level using the regulator on the side of the monitor.