

TWA and STEL Alarm Viewer for Micro IV Gas Detector

1. Download the zip file and extract it to a known location on your hard drive by clicking on the file name and saving it. Make a note of the location where it is saved.
2. Next, extract all files from the zip file to an empty folder on your computer hard drive, including any sub-folders. This will give you the software necessary to view the TWA and STEL information using your internet browser.

Note: *It works best with Firefox and Chrome internet browsers.*

Download the zip file and extract it to a known location on your hard drive.

Document Type:	Zipped Folder
Version:	v4419
Release Date:	05/15/15
File Size:	.5 MB

To Use the Data Logger:

1. Using the DI220 docking station, download the data from your Micro IV.
Note: *The datalogging Interval must be set to 1 minute.*
2. Save the file by selecting "Save As", and save the file as "type" .txt, *not* as the .csv default setting.
3. Now open the folder containing the software for the website that you saved, and double click on "DDS_v4419".
Your browser should open with the GfG logo.
4. Click on the "browse" button, and select the data file you downloaded (it must be a .txt file).
5. Use the navigation buttons on the top and bottom of the viewer to view alarm levels, gas values, sensor graphs, etc...