

GfG USB Driver Installation Guide

1. Make sure the "G450 Datalogger CD-ROM" is installed in your CD-ROM drive.
2. Plug the GfG USB cable into your computer's USB port.
3. A "New hardware found" message appears on your computer screen.
4. Follow the wizard and select "Install from list (advanced)."
5. In the "Search best driver" screen, click on "Search removable media."
6. A screen will appear: "Please wait."
7. A windows warning screen appears, select "Continue anyway."
8. USB driver installation will begin.
9. Select "Finish" when prompted.
10. The message "Found new hardware" will appear again.
11. Repeat steps 4-9, exactly the same as the first time.
12. The message "New hardware installed and ready to use" appears.
13. You now have the USB driver installed properly, and can begin using your USB cable for G450 communication.

Locating the COM port for your USB device

(When using the data program, you will need to identify and select the correct COM port under the "Options" menu before data retrieval can begin.)

1. Click on "Start".
2. Using your mouse, right click on "My Computer."
3. Now, left click on "Properties."
4. Left click on the "Hardware" tab on "System Properties."
5. Left click on the "Device Manager" box.
6. Locate the icon for "Ports" and left click on the "+" symbol.
7. You will see "GfG USB ctr" with a COM number next to it (COM4).
8. This is the COM port your USB cable is using.
9. When you open the G450 Datalogger program, select the "Options" menu, then select the correct COM port for your USB cable.