

Annex to the Operation Manual

Application Instructions LON-Interface D-ReX_01

Version 1



Translation of the original operation manual
245-002.33_AOM_DReX-LonWorks

GfG Instrumentation, Inc.

1194 Oak Valley Dr. Ste. 20
Ann Arbor, MI 48108 USA

Phone: 800-959-0329
Fax: 734-769-1888
Email: info@goodforgas.com
Web: GfGsafety.com/us-en

Version	Datum	Ersteller	Änderung
0.1	25 Oct, 2022	C.Lanzen	Document created, incomplete
0.2	26 Oct, 2022	C.Lanzen	Description of OpenLoopActuator, further comments
0.3	15 Nov, 2022	C.Lanzen	Added annex and changes to LON interface
0.4	18 Nov, 2022	C.Lanzen	Extended description
0.5	6 Dec, 2022	C.Lanzen	Changes regarding discussed topics
0.6	30 Jan, 2022	C.Lanzen	Rework for release
0.7	10 Mar, 2023	C.Lanzen	Added new names of gases
1.0	16 Jan, 2024	F.Böttger	Release by GfG

Table of Contents

Seite

1	Introduction	4
2	Software files	4
3	Functions	4
3.1	Overview of all functional objects	
3.2	Description of all functional objects	5
3.2.1	NodeObject	5
3.2.1.1	Description	5
3.2.1.2	Network interface	5
3.2.1.3	Network variables	5
3.2.1.4	Parameter	7
3.2.1.5	Functions	7
3.2.1.6	Behavior on reset	8
3.2.2	OpenLoopSensor	9
3.2.2.1	Description	9
3.2.2.2	Network interface	9
3.2.2.3	Network variables	10
3.2.2.4	Parameter	17
3.2.2.5	Functions	18
3.2.2.6	Behavior on reset	19
3.2.3	OpenLoopActuator	20
3.2.3.1	Description	20
3.2.3.2	Network interface	20
3.2.3.3	Network variables	20
3.2.3.4	Parameter	20
3.2.3.5	Functions	21
3.2.3.6	Behavior on reset	21
3.3	General description	21
3.3.1	Initial testing of the GMA type	21
3.3.2	Application information for presentation on the GMA	21
3.3.3	Cyclic information query	21
3.3.4	Information query after switching back from configuration mode	21
4	Annex	22
4.1	Enumeration gas_names_t	22
4.2	Enumeration units_t	25

1. Introduction



This document describes the application behavior of the D-ReX LON Works Module.

2. Software files

Software files	D-ReX_01.APB	D-ReX_01.APB
	D-ReX_01.NDL	
	D-ReX_01.XIF	Interface files
	D-ReX_01.XFB	
Resource files	9FA0014600_GFG.typ	Manufacturer-specific declaration of LON data type current version: 1.1
	9FA0014600_GFG.enu	
	9FA0014600_GFG.fmt	
	9FA0014600_GFG.fpt	

3. Functions

3.1 Overview of all functional objects

Object	Number	Overview
NodeObject	1	 <p>NodeObject (SFPTNodeObject 0)</p> <ul style="list-style-type: none"> nviRequest (SNVT_object_request) nvoStatus (SNVT_object_status) nvoFileDirectory (SNVT_address) nvoAlive (SNVT_lev_disc) UCPTaliveInterval (SNVT_time_sec) SCPTdevMajVer (unsigned short) SCPTdevMinVer (unsigned short)
OpenLoopActuator	4	 <p>OpenLoopActuator[0-3] (SFPTOpenLoopActuator 3)</p> <ul style="list-style-type: none"> nviRelay (SNVT_lev_disc) nviRelaySw (SNVT_switch) nvoRelayFb (SNVT_switch) UCPTrelaisEnabled (SNVT_lev_disc)

Object	Number	Overview
OpenLoopSensor	1	<pre> classDiagram class OpenLoopSensor { +nviClearAl(SNVT_lev_disc) +nviClearAlSw(SNVT_switch) +nviAlarm1Rem(SNVT_switch) +nviAlarm2Rem(SNVT_switch) +nviAlarm3Rem(SNVT_switch) +nviFaultRem(SNVT_switch) +nviWarnRem(SNVT_switch) +nviMaintRem(SNVT_switch) +nviAL1lev(SNVT_ppm_f) +nviAL2lev(SNVT_ppm_f) +nviAL3lev(SNVT_ppm_f) +nviAL1OnDelay(SNVT_time_sec) +nviAL2OnDelay(SNVT_time_sec) +nviAL3OnDelay(SNVT_time_sec) +nviAlarmSettings(SNVT_state) +nviDeviceConfig(UNVT_device_config) +SCPTmaxSendTime(SNVT_time_sec) +SCPTminSendTime(SNVT_time_sec) +UCPTIsdMinDelta(SNVT_ppm_f) +UCPTupdMode(UNVT_upd_mode) +UCPTudpTime(SNVT_time_sec) +nvoGasConc(SNVT_ppm_f) +nvoState1(SNVT_state) +nvoState2(SNVT_state) +nvoState3(SNVT_state) +nvoAlarm1_A/_B(SNVT_lev_disc) +nvoAlarm1Sw_A/_B(SNVT_switch) +nvoAlarm2_A/_B(SNVT_lev_disc) +nvoAlarm2Sw_A/_B(SNVT_switch) +nvoAlarm3_A/_B(SNVT_lev_disc) +nvoAlarm3Sw_A/_B(SNVT_switch) +nvoFault_A/_B(SNVT_lev_disc) +nvoFaultSw_A/_B(SNVT_switch) +nvoWarn_A/_B(SNVT_lev_disc) +nvoWarnSw_A/_B(SNVT_switch) +nvoMaint_A/_B(SNVT_lev_disc) +nvoMaintSw_A/_B(SNVT_switch) +nvoAL1lev(SNVT_ppm_f) +nvoAL2lev(SNVT_ppm_f) +nvoAL3lev(SNVT_ppm_f) +nvoAL1OnDelay(SNVT_time_sec) +nvoAL2OnDelay(SNVT_time_sec) +nvoAL3OnDelay(SNVT_time_sec) +nvoAlarmSettings(SNVT_state) +nvoSensorData(UNVTsensorData) +nvoDeviceData(UNVT_device_data) } </pre> <p>The diagram illustrates the structure of the OpenLoopSensor (SFPTOpenLoopSensor 1) object. It is organized into two main columns of methods and attributes, with a central title box at the top.</p> <p>Left Column (Methods):</p> <ul style="list-style-type: none"> nviClearAl (SNVT_lev_disc) nviClearAlSw (SNVT_switch) nviAlarm1Rem (SNVT_switch) nviAlarm2Rem (SNVT_switch) nviAlarm3Rem (SNVT_switch) nviFaultRem (SNVT_switch) nviWarnRem (SNVT_switch) nviMaintRem (SNVT_switch) nviAL1lev (SNVT_ppm_f) nviAL2lev (SNVT_ppm_f) nviAL3lev (SNVT_ppm_f) nviAL1OnDelay (SNVT_time_sec) nviAL2OnDelay (SNVT_time_sec) nviAL3OnDelay (SNVT_time_sec) nviAlarmSettings (SNVT_state) nviDeviceConfig (UNVT_device_config) SCPTmaxSendTime (SNVT_time_sec) SCPTminSendTime (SNVT_time_sec) UCPTIsdMinDelta (SNVT_ppm_f) UCPTupdMode (UNVT_upd_mode) UCPTudpTime (SNVT_time_sec) <p>Right Column (Attributes):</p> <ul style="list-style-type: none"> nvoGasConc (SNVT_ppm_f) nvoState1 (SNVT_state) nvoState2 (SNVT_state) nvoState3 (SNVT_state) nvoAlarm1_A/_B (SNVT_lev_disc) nvoAlarm1Sw_A/_B (SNVT_switch) nvoAlarm2_A/_B (SNVT_lev_disc) nvoAlarm2Sw_A/_B (SNVT_switch) nvoAlarm3_A/_B (SNVT_lev_disc) nvoAlarm3Sw_A/_B (SNVT_switch) nvoFault_A/_B (SNVT_lev_disc) nvoFaultSw_A/_B (SNVT_switch) nvoWarn_A/_B (SNVT_lev_disc) nvoWarnSw_A/_B (SNVT_switch) nvoMaint_A/_B (SNVT_lev_disc) nvoMaintSw_A/_B (SNVT_switch) nvoAL1lev (SNVT_ppm_f) nvoAL2lev (SNVT_ppm_f) nvoAL3lev (SNVT_ppm_f) nvoAL1OnDelay (SNVT_time_sec) nvoAL2OnDelay (SNVT_time_sec) nvoAL3OnDelay (SNVT_time_sec) nvoAlarmSettings (SNVT_state) nvoSensorData (UNVTsensorData) nvoDeviceData (UNVT_device_data)


3.2 Description of all functional objects

3.2.1 NodeObject

3.2.1.1 Description

NodeObject is used to manage all of the application's LonMark objects as well as providing an interface for management commands of the LNS tools.

3.2.1.2 Network interface



3.2.1.3 Network variables

Input variables

<i>nviRequest</i>	Interface for LNS tool management commands and requests; for answers, these are sent via <i>nvoStatus</i>		
Type:	SNVT_object_request		
Structure:	unsigned long	object_id;	
	object_request_t	object_request;	
Value range:	Structural element <i>.object_id</i> :		
	0	NodeObject	
	1	OpenLoopSensor	
	2-5	OpenLoopActuator[0-3]	
	Structural element <i>.object_request</i> :		
	0	RQ_NORMAL	
	2	RQ_UPDATE_STATUS	Provides the current status of the individual functional block
	5	RQ_REPORT_MASK	Provides the supported status flags of the functional block
	17	RQ_RESET	A request for the Node object triggers a software reset
Default settings:	{0, RQ_NORMAL} (0, 0)		

Outlet variables

<i>nvoStatus</i>	Interface for LNS tool management commands; answers to requests via <i>nviRequest</i>
Type:	SNVT_object_status
	unsigned long <i>object_id</i> ; unsigned <i>invalid_id</i> :1; unsigned <i>invalid_request</i> :1; unsigned <i>disabled</i> :1; unsigned <i>out_of_limits</i> :1; unsigned <i>open_circuit</i> :1; unsigned <i>out_of_service</i> :1; unsigned <i>mechanical_fault</i> :1; unsigned <i>feedback_failure</i> :1; unsigned <i>over_range</i> :1; unsigned <i>under_range</i> :1; unsigned <i>electrical_fault</i> :1; unsigned <i>unable_to_measure</i> :1; unsigned <i>comm_failure</i> :1; unsigned <i>fail_self_test</i> :1; unsigned <i>self_test_in_progress</i> :1; unsigned <i>locked_out</i> :1; unsigned <i>manual_control</i> :1; unsigned <i>in_alarm</i> :1; unsigned <i>in_override</i> :1; unsigned <i>report_mask</i> :1; unsigned <i>programming_mode</i> :1; unsigned <i>programming_fail</i> :1; unsigned <i>alarm_notify_disabled</i> :1; unsigned <i>reset_complete</i> :1; unsigned <i>reserved2</i> :8;
Value range:	Structural element <i>.object_id</i> : 0 NodeObject 1 OpenLoopSensor 2-5 OpenLoopActuator[0-3] Structural element <i>.invalid_id</i> : 0 the request's <i>nviRequest.object_id</i> is valid 1 the request's <i>nviRequest.object_id</i> is invalid Structural element <i>.invalid_request</i> : 0 the <i>nviRequest.object_request</i> is supported 1 the <i>nviRequest.object_request</i> is not supported Structural element <i>.report_mask</i> : 0 <i>nvoStatus</i> contains status of the functional block from <i>.object_id</i> ((if bits above are not 1) 1 <i>nvoStatus</i> contains ReportMask of the functional block from <i>object_id</i> .
Default settings:	All structural elements 0
Transmission:	After requests to <i>nviRequest</i>
<i>nvoFileDirectory</i>	Interface for parameter access of the LNS tools
Type:	SNVT_address
Value range:	SNVT_address
<i>nvoAlive</i>	Output for external failure monitoring of the node
Type:	SNVT_lev_disc
Value range:	0 ST_OFF on voltage recovery and after initializing, if <i>UCPTaliveInterval</i> = 0 1 ST_LOW after initializing, if <i>UCPTaliveInterval</i> > 0 ST_OFF (0)
Default settings:	ST_OFF (0)
Transmission:	After reset and cyclically according to <i>UCPTaliveInterval</i>

3.2.1.4 Parameter

<i>UCPTaliveInterval</i>	Transmission interval for <i>nvoAlive</i>
Type:	SNVT_time_sec
Value range:	0,0 - no cyclic transmission 0,1 ... 6553,5 - Transmission interval in seconds
Default settings:	0,0 (0) - no cyclic transmission
<i>SCPTdevMajVer</i>	Main version of the LON application
Type:	unsigned short, constant
Value range:	0 ... 255
Default settings:	1
<i>SCPTdevMinVer</i>	Sub version of the LON application
Type:	unsigned short, constant and device-specific
Value range:	0 ... 255
Default settings:	0

3.2.1.5 Functions

NodeObject provides the management interfaces required by the LNS tools as well as several further functions:

Failure monitoring

It also provides a network variable, *nvoAlive*, which can be used to monitor the presence or availability of the node. If a cyclic transmission interval of the *nvoAlive* is set on the *UCPTaliveInterval* parameter, the regular receipt of telegrams can be monitored on another device within the network to determine failures of the device.

Information on current version

The current version of the LON application can be concluded from the device itself, using the *SCPTdevMajVer* and *SCPTdevMinVer* parameters.

3.2.1.6 Behavior on reset


Depending on the *UCPTaliveInterval* value, *nvoAlive* is set to either ST_OFF oder ST_LOW and sent. If necessary, the time tracker for cyclic transmission is started as well.

3.2.2 OpenLoopSensor

3.2.2.1 Description

OpenLoopSensor is used for capturing all sensor data and settings of measuring point 1 and the GMA. It also allows you to change settings can and activate sensor data simulation.

3.2.2.2 Network interface



3.2.2.3 Network variables

Input variables

<i>nviClearAl</i>	This inlet is used to acknowledge the alarm of measuring point 1.		
Type:	SNVT_lev_disc		
Value range:	0	ST_OFF	no acknowledgement
	1	ST_LOW	acknowledge alarms
Default settings:	0	ST_OFF	no acknowledgement
<i>nviClearAlSw</i>	This inlet is used to acknowledge the alarm of measuring point 1.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	no acknowledgement
	(x 1)	x/2% (x>0)	acknowledge alarms
Default settings:	(0 0)	0,0%	no acknowledgement
<i>nviAlarm1Rem</i>	This inlet can be used to simulate Alarm 1, if it is activated on the GMA.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	Simulation for Alarm 1 deactivated
	(x 1)	x/2% (x>0)	Alarm 1 active (simulated)
Default settings:	(0 0)	0,0%	Simulation for Alarm 1 deactivated
<i>nviAlarm2Rem</i>	This inlet can be used to simulate Alarm 2, if it is activated on the GMA.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	Simulation for Alarm 2 deactivated
	(x 1)	x/2% (x>0)	Alarm 2 active (simulated)
Default settings:	(0 0)	0,0%	Simulation for Alarm 2 deactivated
<i>nviAlarm3Rem</i>	This inlet can be used to simulate Alarm 3, if it is activated on the GMA.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	Simulation for Alarm 3 deactivated
	(x 1)	x/2% (x>0)	Alarm 3 active (simulated)
Default settings:	(0 0)	0,0%	Simulation for Alarm 3 deactivated
<i>nviFaultRem</i>	This inlet can be used to simulate a "fault" on measuring point 1.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	Simulation of "fault" MST1 deactivated
	(x 1)	x/2% (x>0)	"Fault" MST1 active (simulated)
Default settings:	(0 0)	0,0%	Simulation of "fault" MST1 deactivated
<i>nviWarnRem</i>	This inlet can be used to simulate a "fault" on measuring point 1.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	Simulation "maintenance request" MST1 deactivated
	(x 1)	x/2% (x>0)	"Maintenance request" MST1 active (sim.)
Default settings:	(0 0)	0,0%	Simulation "maintenance request" MST1 deactivated
<i>nviMaintRem</i>	This inlet can be used to simulate "maintenance" on measuring point 1.		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	Simulation "Maintenance" MST1 deactivated
	(x 1)	x/2% (x>0)	"Maintenance" MST1 active (simulated)
Default settings:	(0 0)	0,0%	Simulation "Maintenance" MST1 deactivated
<i>nviAl1Lev</i>	Setting the alarm threshold for Alarm 1. The value must be entered in the unit specified in <i>nvoSensorData.gas_unit</i> .		
Type:	SNVT_ppm_f		
Value range:	0 - 3.4028234663852886E+038		
Default settings:	0		

<i>nviAl2Lev</i>	Setting the alarm threshold for Alarm 2. The value must be entered in the unit specified in <i>nvoSensorData.gas_unit</i> .
Type:	SNVT_ppm_f
Value range:	0 - 3.4028234663852886E+038
Default settings:	0
<i>nviAl3Lev</i>	Setting the alarm threshold for Alarm 3. The value must be entered in the unit specified in <i>nvoSensorData.gas_unit</i> .
Type:	SNVT_ppm_f
Value range:	0 - 3.4028234663852886E+038
Default settings:	0
<i>nviAl1OnDelay</i>	Setting the activation delay for Alarm 1.
Type:	SNVT_time_sec
Value range:	0,0 – 900,0 s
Default settings:	0,0 s
<i>nviAl2OnDelay</i>	Setting the activation delay for Alarm 2.
Type:	SNVT_time_sec
Value range:	0,0 – 900,0 s
Default settings:	0,0 s
<i>nviAl3OnDelay</i>	Setting the activation delay for Alarm 3.
Type:	SNVT_time_sec
Value range:	0,0 – 900,0 s
Default settings:	0,0 s
<i>nviAlarmSettings</i>	<i>Inhibit and Latch settings of Alarms 1 to 3.</i>
Type:	SNVT_state, meaning of individual elements explained below: <i>.bit0 - .bit1</i> Inhibit of Alarm 1 <i>.bit2 - .bit3</i> Latching function of Alarm 1 <i>.bit4 - .bit5</i> Inhibit of Alarm 2 <i>.bit6 - .bit7</i> Latching function of Alarm 2 <i>.bit8 - .bit9</i> Inhibit of Alarm 3 <i>.bit10 - .bit11</i> Latching function of Alarm 3 Elements <i>bit12</i> to <i>bit15</i> are not currently in use.
Value range:	The following applies to the values of the bit pairings used: 0 (0b00) no changes 1 (0b01) deactivate (<i>.bitX</i> is set) 2 (0b10) activate (<i>.bitX-1</i> is set) 4 (0b11) no changes (both bits are set)
Default settings:	All Bits on 0 (no changes)
<i>nviDeviceConfig</i>	Schnittstelle zur Änderung der Zugangsdaten
Type:	UNVT_device_config
Structure:	pass_t pw_config_old; unsigned char pw_id_old[4]; unsigned char pw_pin_old[4]; pass_t pw_config_new; unsigned char pw_id_new[4]; unsigned char pw_pin_new[4];
Value range:	Structural element <i>.pw_config_*</i> : 0 PASSWORD_OFF no password necessary 1 PASSWORD_ON Use password structural element structural elements <i>.pw_id_*</i> und <i>.pw_pin_*</i> : 4 Basic ASCII characters each (0-127)
Default settings:	All structural elements 0

Outlet variables

nvoState1 GMA status outlet.

Type: SNVT_state; meaning of individual elements explained below:

- .bit0* Startup*
- .bit1* Fault*
- .bit2* Maintenance*
- .bit3* Maintenance request*
- .bit4* configuration mode*
- .bit5 - .bit7* not used
- .bit8* Error in communication with GMA
- .bit9* Password error
- .bit10* Error concerning relay control
- .bit11* min. 1 relay can be addressed via LON
- .bit12* logic status Relais1*
- .bit13* logic status Relais2*
- .bit14* logic status Relais3*
- .bit15* logic status Relais4*

* values identified by GMA

Value range: The following applies to used *.bitX*:
0 – not active
1 – active

Default settings: All elements are 0 values until they are first read out.

Transmission: Upon changing a *.bitX* and cyclically according to *SCPTmaxSendTime*

nvoState2 Output of measuring point 1's Status 1.

Type: SNVT_state; meaning of individual elements explained below:

- .bit0* Active (MST1)
- .bit1* Inhibited (MST1)
- .bit2* Simulation (MST1)
- .bit3* Measured value valid (MST1)
- .bit4* Fault (MST1)
- .bit5* Maintenance (MST1)
- .bit6* Maintenance request (MST1)
- .bit7* PreAlarm (MST1)
- .bit8* Alarm1 (GMA)
- .bit9* Alarm2 (GMA)
- .bit10* Alarm3 (GMA)
- .bit11* Alarm4 (GMA)
- .bit12 - .bit14* not in use
- .bit15* Ambiguity (GMA)

Value range: The following applies to used elements:
0 – not active
1 – active

Default settings: All elements are 0 values until they are first read out.

Transmission: On adjustments and cyclically according to *SCPTmaxSendTime*

nvoState3 Output of measuring point 1's Status2. The values determined entirely via the GMA are read out cyclically.

Type: SNVT_state; meaning of individual elements explained below:

- .bit0 - .bit2* Over-/Underrange (MST1)
- .bit3* Fault Pyrolizer (MST1)
- .bit4* Fault Gas Flow (MST1)
- .bit5* Fault Line Integrity (MST1)
- .bit6 - .bit11* not currently in use
- .bit12 - .bit15* status indication (MST1)

Value range: Für *.bit0 - .bit2* and *.bit12 - .bit15*:
see Modbus specifications
The following applies to *.bit3 - .bit5*:
0 – not active
1 – active

Default settings: All Bits are 0 values until they are first read out.

Transmission: On adjustments and cyclically according to *SCPTmaxSendTime*

nvoGasConc Output of measuring point 1's measured value.
The value is given in the unit specified in *nvoSensorData.gas_unit*.
Type: SNVT_ppm_f
Value range: 0 - 3.4028234663852886E+038
Default settings: 0
Transmission: On adjustments of at least *UCPTIsdMinDelta* and cyclically according to *SCPT-maxSendTime*, with a minimum interval of *SCPTminSendTime*

nvoAlarm1_A
nvoAlarm1_B Output for Alarm1. The value is provided for 2 separate zones for further evaluation (A and B).
Type: SNVT_lev_disc
Value range: 0 ST_OFF Alarm1 not active
1 ST_LOW Alarm1 active
Default settings: 0 ST_OFF Alarm1 not active
Transmission: Depending on the *UCPTupdMode.alarm1_** settings (* A or B)

nvoAlarm1Sw_A
nvoAlarm1Sw_B Alarm1 output. The value is provided for 2 separate zones for further evaluation (A and B).
Type: SNVT_switch
Value range: (0 0) 0,0% Alarm1 not active
(200 1) 100,0% Alarm1 active
Default settings: (0 0) 0,0% Alarm1 not active
Transmission: Depending on the *UCPTupdMode.alarm1_** settings (* A or B)

nvoAlarm2_A
nvoAlarm2_B Alarm2 output. The value is provided for 2 separate zones for further evaluation (A and B).
Type: SNVT_lev_disc
Value range: 0 ST_OFF Alarm2 not active
1 ST_LOW Alarm2 active
Default settings: 0 ST_OFF Alarm2 not active
Transmission: Depending on the *UCPTupdMode.alarm2_** settings (* A or B)

nvoAlarm2Sw_A
nvoAlarm2Sw_B Alarm2 output. The value is provided for 2 separate zones for further evaluation (A and B).
Type: SNVT_switch
Value range: (0 0) 0,0% Alarm2 not active
(200 1) 100,0% Alarm2 active
Default settings: (0 0) 0,0% Alarm2 not active
Transmission: Depending on the *UCPTupdMode.alarm2_** settings (* A or B)

nvoAlarm3_A
nvoAlarm3_B Alarm3 output. The value is provided for 2 separate zones for further evaluation (A and B).
Type: SNVT_lev_disc
Value range: 0 ST_OFF Alarm3 not active
1 ST_LOW Alarm3 active
Default settings: 0 ST_OFF Alarm3 not active
Transmission: Depending on the *UCPTupdMode.alarm3_** settings (* A or B)

nvoAlarm3Sw_A
nvoAlarm3Sw_B Alarm3 output. The value is provided for 2 separate zones for further evaluation (A and B).
Type: SNVT_switch
Value range: (0 0) 0,0% Alarm3 not active
(200 1) 100,0% Alarm3 active
Default settings: (0 0) 0,0% Alarm3 not active
Transmission: Depending on the *UCPTupdMode.alarm3_** settings (* A or B)

<i>nvoFault_A</i> <i>nvoFault_B</i>	Fault status output. The value is provided for 2 separate zones for further evaluation (A and B).		
Type:	SNVT_lev_disc		
Value range:	0	ST_OFF	no fault
	1	ST_LOW	fault
Default settings:	0	ST_OFF	no fault
Transmission:	Depending on the <i>UCPTupdMode.fault_*</i> settings (* A or B)		
<i>nvoFaultSw_A</i> <i>nvoFaultSw_B</i>	Ausgabe für Störungs-Zustand. Der Wert wird für 2 getrennte Zonen zur weiteren Auswertung zur Verfügung gestellt (A und B).		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	no fault
	(200 1)	100,0%	fault
Default settings:	(0 0)	0,0%	no fault
Transmission:	Depending on the <i>UCPTupdMode.fault_*</i> settings (* A or B)		
<i>nvoSWarn_A</i> <i>nvoSWarn_B</i>	Maintenance request status output. The value is provided for 2 separate zones for further evaluation (A and B).		
Type:	SNVT_lev_disc		
Value range:	0	ST_OFF	no maintenance request
	1	ST_LOW	maintenance request
Default settings:	0	ST_OFF	no maintenance request
Transmission:	Depending on the <i>UCPTupdMode.warn_*</i> settings (* A or B)		
<i>nvoSWarnSw_A</i> <i>nvoSWarnSw_B</i>	Maintenance request status output. The value is provided for 2 separate zones for further evaluation (A and B).		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	no maintenance request
	(200 1)	100,0%	maintenance request
Default settings:	(0 0)	0,0%	no maintenance request
Transmission:	Depending on the <i>UCPTupdMode.warn_*</i> settings (* A or B)		
<i>nvoMaint_A</i> <i>nvoMaint_B</i>	Maintenance status output. The value is provided for 2 separate zones for further evaluation (A and B).		
Type:	SNVT_lev_disc		
Value range:	0	ST_OFF	no maintenance
	1	ST_LOW	maintenance active
Default settings:	0	ST_OFF	no maintenance
Transmission:	Depending on the <i>UCPTupdMode.warn_*</i> settings (* A or B)		
<i>nvoMaintSw_A</i> <i>nvoMaintSw_B</i>	Maintenance status output. The value is provided for 2 separate zones for further evaluation (A and B).		
Type:	SNVT_switch		
Value range:	(0 0)	0,0%	no maintenance
	(200 1)	100,0%	maintenance
Default settings:	(0 0)	0,0%	no maintenance
Transmission:	Depending on the <i>UCPTupdMode.warn_*</i> settings (* A or B)		
<i>nvoAl1Lev</i>	Output of measuring point 1's alarm threshold for Alarm 1, as set on the GMA. The value is given in the unit specified in <i>nvoSensorData.gas_unit</i> .		
Type:	SNVT_ppm_f		
Value range:	0 - 3.4028234663852886E+038		
Default settings:	0		
Transmission:	On adjustments		

<i>nvoAl2Lev</i>	Output of measuring point 1's alarm threshold for Alarm 2, as set on the GMA. The value is given in the unit specified in <i>nvoSensorData.gas_unit</i> .
Type:	SNVT_ppm_f
Value range:	0 - 3.4028234663852886E+038
Default settings:	0
Transmission:	On adjustments
<i>nvoAl3Lev</i>	Output of measuring point 1's alarm threshold for Alarm 3, as set on the GMA. The value is given in the unit specified in <i>nvoSensorData.gas_unit</i> .
Type:	SNVT_ppm_f
Value range:	0 - 3.4028234663852886E+038
Default settings:	0
Transmission:	On adjustments
<i>nvoAl1OnDelay</i>	Output of measuring point 1's activation delay for Alarm 1, as set on the GMA.
Type:	SNVT_time_sec
Value range:	0,0 – 900,0 s
Default settings:	0,0 s
Transmission:	On adjustments
<i>nvoAl2OnDelay</i>	Output of measuring point 1's activation delay for Alarm 2, as set on the GMA.
Type:	SNVT_time_sec
Value range:	0,0 – 900,0 s
Default settings:	0,0 s
Transmission:	On adjustments
<i>nvoAl3OnDelay</i>	Activation delay of Alarm 3 from measuring point 1.
Type:	SNVT_time_sec
Value range:	0,0 – 900,0 s
Default settings:	0,0 s
Transmission:	On adjustments
<i>nvoAlarmSettings</i>	Inhibit and Latch values of Alarms 1 to 3 as well as the alarm unlock status of all measuring point 1 alarms. .
Type:	SNVT_state; meaning of individual elements explained below:
	.bit0 - .bit1 Inhibit of Alarm 1
	.bit2 - .bit3 Latching function of Alarm 1
	.bit4 - .bit5 Inhibit of Alarm 2
	.bit6 - .bit7 Latching function of Alarm 2
	.bit8 - .bit9 Inhibit of Alarm 3
	.bit10 - .bit11 Latching function of Alarm 3
	.bit12 Unlock status of Alarm 1
	.bit13 Unlock status of Alarm 2
	.bit14 Unlock status of Alarm 3
	.bit15 not used
Value range:	The following applies to used Bit pairings (.bit0 - .bit11):
	1 (0b01) inactive (.bitX is set)
	2 (0b10) active (.bitX-1 is set)
	The following applies to the alarm unlock status (.bit12 - .bit14):
	0 inactive Alarm not unlocked
	1 active Alarm unlocked
Default settings:	All elements are 0 values until they are first read out.
Transmission:	On adjustments

<i>nvoDeviceData</i>	The device data contains Text1 of both measuring point 1 and the GMA as well as the current password settings. The measuring point's Text1 is read out on resets and when returning from configuration mode. The displayed password information is used alongside ID "LON" for unlocking purposes when writing parameters.	
Type:	UNVT_device_data	
Struktur:	unsigend char location[14]; pass_t pw_setting_active; unsigned char password[4];	
Value range:	Structural elemente .location und .password: Basis-ASCII-Zeichen (0-127) Structural element .pw_setting_active: 0 PASSWORD_OFF no password necessary 1 PASSWORD_ON password necessary	
Default settings:	.location: {0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0} .pw_setting_active: {1} (PASSWORD_ON) .password: {48, 48, 48, 48} ("0000")	
Transmission:	On adjustments and cyclically according to SCPTmaxSendTime	
<i>nvoSensorData</i>	Measuring point 1 sensor data output.	
Type:	UNVTsensorData	
Struktur:	gas_name_t gas_name; gas_unit_t gas_unit; unsigend char part_number[10]; unsigend char part_serial[10]; SNVT_date_cal first_calibration_date; SNVT_date_cal recent_calibration_date; mit SNVT_date_cal - Struktur: unsigned long year; unsigned short month; unsigned short day;	
Value range:	Structural elemente .part_number and .part_serial: Basic ASCII characters (0-127) Structural elements .first_calibration_date and .recent_calibration_date: .year: 0 - 3000 .month: 1 - 12 .day: 1 - 31 Structural element .gas_name see enumeration gas_name_t (Annex) Structural element .gas_unit see enumeration gas_unit_t (Annex)	
Default settings:	Structural elemente .part_number and .part_serial: Each {0, 0, 0, 0, 0, 0, 0, 0, 0, 0} until first readout. Structural elements .first_calibration_date and .recent_calibration_date: {0, 0, 0} no valid date until first readout. Structural element .gas_name GN_NOTHING until first readout. Structural element .gas_unit UN_NOTHING until first readout	
Transmission:	On adjustments and cyclically according to SCPTmaxSendTime	

3.2.2.4 Parameter

<i>SCPTmaxSendTime</i>	Transmission interval for network variables <i>nvoGasConc</i> , <i>nvoState1</i> , <i>nvoState2</i> , <i>nvoState3</i> , <i>nvoSensorData</i> and <i>nvoDeviceData</i> . The transmission interval is considered separately for each of the mentioned network variable.
Type:	SNVT_time_sec
Value range:	0,0 - no cyclic transmission 0,1 ... 6553,5 - Transmission interval in seconds
Default settings:	0,0 (0) - no cyclic transmission
<i>SCPTminSendTime</i>	Minimum time interval for telegrams on <i>nvoGasConc</i> .
Type:	SNVT_time_sec
Value range:	0,0 - no minimum interval 0,1 ... 6553,5 - minimum interval in seconds
Default settings:	0,0 (0) - no minimum interval
<i>UCPTIsdMinDelta</i>	Minimum change for telegrams on <i>nvoGasConc</i> . The value must be entered in the unit specified in <i>nvoSensorData.gas_unit</i> .
Type:	SNVT_ppm_f
Value range:	0 - 3.4028234663852886E+038
Default settings:	0
<i>UCPTupdMode</i>	This parameter determines the transmission modes. They specify how alarms as well as die fault, maintenance and maintenance requirement statuses are transferred to the corresponding NVOs.
Type:	UNVT_upd_mode
Struktur:	
	upd_mode_t alarm1_A;
	upd_mode_t alarm1_B;
	upd_mode_t alarm2_A;
	upd_mode_t alarm2_B;
	upd_mode_t alarm3_A;
	upd_mode_t alarm3_B;
	upd_mode_t maint_A;
	upd_mode_t maint_B;
	upd_mode_t fault_A;
	upd_mode_t fault_B;
	upd_mode_t warn_A;
	upd_mode_t warn_B;
Value range:	The following applies to all elements: 0 UM_ON_CHANGE Transmission on adjustments 1 UM_WHEN_ON Transmission on adjustments and cyclically if active, interval see <i>UCPTupdTime</i> 2 UM_HEARTBEAT Transmission upon changes and cyclically, interval see <i>UCPTupdTime</i>
Default settings:	The following applies to all elements: UM_ON_CHANGE (0) Transmission on adjustments
<i>UCPTupdTime</i>	Duration of the transmission cycle for transmission modes UM_WHEN_ON and UM_HEARTBEAT (see <i>UCPTupdMode</i>)
Type:	SNVT_time_sec
Value range:	0,0 - no cyclic transmission 0,1 ... 6553,5 - transmission cycle in seconds
Default settings:	0,0 (0) - no cyclic transmission

3.2.2.5 Functions

The *OpenLoopSensor* object is used to capture all device information of the GMA and measuring point 1 as well as their configuration and runtime data. The configuration of alarms can also be adjusted.

Logging measured values

The measured value taken on measuring point 1 is read out on *nvoGasConc*. The value is read out cyclically and therefore has to be evaluated according to the gas unit specified in *nvoSensorData*. A minimum time interval (*SCPTminSendTime*) between transmitted values, a transmission cycle (*SCPTmaxSendTime*) and a value for a minimum change (*UCPTIsdMinDelta*) can be specified for the measured value. Consider that the selected settings for these three parameters influence the LON network's bus load.

Logging alarms

The occurrence of an alarm which has been configured in measuring point 1 (Alarm 1 to 3) is detected and indicated by reading out status 1 of measuring point 1 every second. It is given out for 2 separate zones (A and B). The network variable outputs *nvoAlarm1_**, *nvoAlarm2_** and *nvoAlarm3_** of the SNVT_lev_disc type and the network variables *nvoAlarm1Sw_**, *nvoAlarm2Sw_** as well as *nvoAlarm3Sw_** of type SNVT_switch are available. The transmission of the values can be influenced by defining the transmission mode (*UCPTupdMode*) and the associated setting of a transmission cycle (*UCPTupdTime*). Consider that the selected settings for these two parameters influence the LON network's bus load.

Acknowledging alarms

There are two input network variables available to acknowledge measuring point 1's alarms: *nviClearAl* of the SNVT_lev_disc type and *nviClearAlSw* of the SNVT_switch type. On both inlets, an acknowledgement is only triggered on switching from "no acknowledgement" to "acknowledge alarms". The acknowledgement is sent to the GMA. The flashing LEDs inside the GMA are then reset and the displayed information changes.

Device data

The device data, which can be read out on *nvoDeviceData*, contains Text1 of both measuring point 1 and the GMA as well as the current password settings. The measuring point's Text1 is read out on resets and when returning from configuration mode on the GMA. The displayed password information is used alongside ID "LON" for unlocking purposes when writing parameters. The transmission cycle set in *SCPTmaxSendTime* is used to transmit *nvoDeviceData* in the LON network. Consider that the transmission cycle's configuration influences the LON network's bus load.

Sensor data of measuring point 1

Measuring point 1's sensor data is read out on *nvoSensorData*. It contains information on the names of the measured gases and the unit used for *nvoGasConc* as well as the sensor's component and serial number and the date of its first and latest sensor calibration. The sensor data is read out on measuring point 1 upon voltage recovery, software reset and after returning from configuration mode. The transmission cycle set in *SCPTmaxSendTime* is used for transmission in the LON network. Consider that the transmission cycle's configuration influences the LON network's bus load.

Alarm configuration

The settings (alarm threshold, activation delay, Inhibit and Latch) can be adjusted for all three alarms. The alarms are not implicitly activated though, but must be activated using the GMA's configuration tool. The activation status is read out by measuring point 1 and then indicated on *nvoAlarmSettings* (.bit12 to .bit14). You will need the access data stored in the LON node to adjust the alarm configuration settings on the GMA. Since the parameters can also be adjusted using the GMA's configuration tool, there are also corresponding outlet network variables. All GMA parameters which have been read out are updated after writing the individual parameter, on voltage recovery or software resets as well as after you return from configuration mode. The alarm thresholds for the individual alarms can be adjusted on *nviAl1Lev*, *nviAl2Lev* and *nviAl3Lev* respectively. The alarm threshold currently set on measuring point 1 are indicated on *nvoAl1Lev*, *nvoAl2Lev* and *nvoAl3Lev*. You can use the inlet network variables *nviAl1OnDelay*, *nviAl2OnDelay* and *nviAl3OnDelay* to adjust the activation delay times. The activation delay times currently set on measuring point 1 are indicated on *nvoAl1OnDelay*, *nvoAl2OnDelay* and *nvoAl3OnDelay*. There may be disparities in the values which are read back, due to the different resolutions of the LON node and the GMA. The Inhibit and Latch values for Alarms 1 to 3 may also be adjusted here. Use the *nviAlarmSettings* inlet to do so. The current Inhibit and Latch settings are indicated on *nvoAlarmSettings* (.bit0 bis .bit11).

Alarm simulation

Alarms 1 to 3 can be simulated using *nviAlarm1Rem*, *nviAlarm2Rem* and *nviAlarm3Rem*. Consider the set activation delay. Alarms which are not unlocked on the GMA cannot be simulated. Only active conditions may be simulated. Simulations can be deactivated explicitly or end automatically on a reset of the GMA. Structural element bit2 in *nvoState2* indicates whether a fault, maintenance, a maintenance request or one of the alarms is being simulated.

Logging faults, maintenance and maintenance requests

"Fault", "maintenance request" and "maintenance" statuses are each determined from an OR-combination of the corresponding GMA status information and measuring point 1's status1. Both statuses are read out cyclically. The "Fault" status is given for 2 separate zones (A and B) each, both on the outlet network variable *nvoFault_** of the *SNVT_lev_disc* type and on *nvoFaultSw_** of the *SNVT_switch* type. The "Maintenance request" status is given for zones A and B too, both on the outlet network variable *nvoSWarn_** of the *SNVT_lev_disc* type and *nvoSWarnSw_** of the *SNVT_switch* type. The "Maintenance" status is given for both zones, both on the outlet network variable *nvoMaint_** of the *SNVT_lev_disc* type and on *nvoMaintSw_** of the *SNVT_switch* type. The transmission of values may be influenced by the *UCPTupdMode* and *UCPTupdTime* parameters. Consider that the selected settings for these two parameters influence the LON network's bus load.

Simulating faults, maintenance and maintenance requests

The "Fault", "Maintenance request" and "Maintenance" statuses can be simulated using *nviFaultRem*, *nviSWarnRem* and *nviMaintRem*. Only the currently active conditions may be simulated. Simulations can be deactivated explicitly or end automatically on a reset of the GMA. Structural element bit2 in *nvoState2* indicates whether a fault, maintenance, a maintenance request or one of the alarms is being simulated.

Logging other GMA statuses

Other identified GMA statuses or information on the communication with the GMA are indicated on *nvoState1*. In addition to the fault, maintenance and maintenance request statuses, which are also available as individual NVs, the GMA startup, an active configuration mode and status information on the internal relays of the GMA can also be found there. It also indicates whether one or more of the internal relays of the GMA can be addressed via LON. Communication errors between the GMA and the LON-Gateway, faults on unlocking (writing of parameters) as well as faults when addressing relays are signaled too. The GMA statuses are read out cyclically. The transmission cycle set in *SCPTmaxSendTime* is used for transmission in the LON network. Consider that the transmission cycle's configuration influences the LON network's bus load.

Logging other measuring point statuses

Other identified measuring point 1 statuses are indicated on the outlet network variables *nvoState2* and *nvoState3*. *nvoState2* contains general status and alarm notifications of measuring point 1, while *nvoState3* contains more detailed information about faults and statuses. This data is read out cyclically. The transmission cycle set in *SCPTmaxSendTime* is used for transmission in the LON network. Consider that the transmission cycle's configuration influences the LON network's bus load.

Unlocking the writing parameter values

You will need the access information stored in the LON node to parameterize measuring point 1's alarms, simulate alarms and statuses as well as to address relays via *OpenLoopActuator* objects. The access information currently stored in the LON node (Flags and PIN) are indicated on *nvoDeviceData* for monitoring purposes. If the access information is changed in the GMA (using D-ReX-Config), the new information can be adjusted using *nviDeviceConfig* in the LON application. To enter the new data, you will also need the previous access information.

3.2.2.6 Behavior on reset


On reset, the output values are updated by reading the information from the GMA.

OpenLoopActuator

3.2.3.1 Description

The OpenLoopActuator objects are used to address the internal relays 1-4 of the GMA as well as to detect their status.

3.2.3.2 Network interface



3.2.3.3 Network variables

Input variables

<i>nviRelay</i>	Addressing the corresponding internal relays of the GMA.		
Type:	SNVT_lev_disc		
Value range:	0	ST_OFF	relay logically off
	1	ST_LOW	relay logically on
Default settings:	0	ST_OFF	relay logically off

<i>nviRelaySw</i>	Addressing the corresponding internal relays of the GMA.		
Type:	SNVT_switch		
Value range:	(x 0) 0,0%		relay logically off
	(0 1) 0,0%		relay logically off
	(x*2 1) x%		relay logically on, condition: x>0
Default settings:	0,0% (0 0)		relay logically off

Outlet variables

<i>nvoRelayFb</i>	Outlet of the assigned relay's status.		
Type:	SNVT_switch		
Value range:	(0 0) 0,0%		relay logically off
	(200 1) 100,0%		relay logically on
Default settings:	0,0% (0 0)		relay logically off
Transmission:	After changes and resets		

3.2.3.4 Parameter

UCPTrelaisEnabled	This parameter determines whether the corresponding relay can be addressed via <i>nviRelay</i> and <i>nviRelaySw</i> .		
Type:	SNVT_lev_disc		
Value range:	0	ST_OFF	addressing relay locked
	1	ST_LOW	addressing relay unlocked
Default settings:	0	ST_OFF	addressing relay locked

3.2.3.5 Functions

The OpenLoopActuator object is used to register the status of the first four internal relays of the GMA. If a GMA relay is unlocked it can be addressed via LON and thus the LON network. The relays are assigned to the functional blocks in the following way:

Functional block	Relays
OpenLoopActuator[0]	Relay1, GMA internal relay
OpenLoopActuator[1]	Relay2, GMA internal relay
OpenLoopActuator[2]	Relay3, GMA internal relay
OpenLoopActuator[3]	Relay4, GMA internal relay

Unlocking the addressing functionality

The unlocking process can / has to be performed on two different layers. 1: An assigned relay (see table) can only be addressed if the GMA configuration allows for it to be addressed via LON. 2: UCPTrelaisEnabled can additionally be used to lock it on the LON level. This value is only valid in LON and does not affect the GMA configuration's relay assignment. You will also need the access information stored in OpenLoopSensor to address the relay.

Addressing relays

You may address relays via nviRelay or nviRelaySw. They are treated equivalently and will be processed in the order they were received in. Any addressing of the assigned relays is only transmitted to the GMA if it is unlocked on UCPTrelaisEnabled. Inside the GMA, it is only processed if the GMA relay is unlocked and thus enabled to be addressed via LON. If this is not the case, any attempt of addressing it will result in a nvoState1 error notification of the OpenLoopSensor object. It is only processed when a telegram is received.

Relay status

The status of the assigned relay is indicated on nvoRelayFb. It is determined based on the GMA status, which is read out cyclically. The status will also be indicated if it is locked for addressing purposes.

3.2.3.6 Behavior on reset

Resets will trigger an update and a status report as a result of reading out the GMA status.

3.3 General description

This section contains information on additional general behavior regarding the communication with the GMA, which cannot be explicitly influenced or seen on the LON interface.

3.3.1 Initial testing of the GMA type

In case of returning voltages (voltage recovery), the system first checks whether it is a GMA type approved for cooperation.

3.3.2 Application information for presentation on the GMA

In case of voltage recovery or after returning from configuration mode, the Neuron ID as well as application and information on the hardware version are sent to the GMA for display.

3.3.3 Cyclic information query

After initializing, the status of the GMA and measuring point 1 are requested every second.

3.3.4 Information query after switching back from configuration mode

Additional information is read out after the GMA switches back from configuration mode. This includes not only the statuses of the GMA and measuring point 1 but also sensor data, texts and alarm parameters (alarm threshold, activation delay, Inhibit and Latch) of measuring point 1.

4 Annex

4.1 Enumeration gas_names_t

```
typedef enum gas_names_t {
    /*-128 */    GN_ETHYLLACTAT = -128,
    /*-127 */    GN_AMMONIUM_ION = -127,
    /*-126 */    GN_R11_TRICHLORFLUORMETHAN = -126,
    /*-125 */    GN_R245FA_PENTAFLUORPROPAN = -125,
    /*-124 */    GN_PROPIN = -124,
    /*-123 */    GN_CARBON_DISULFIDE = -123,
    /*-122 */    GN_BORTRICHLORID = -122,
    /*-121 */    GN_BORTRIFLUORID = -121,
    /*-120 */    GN_BROMMETHAN = -120,
    /*-119 */    GN_2_BUTHANOL = -119,
    /*-118 */    GN_LANDFILL_GAS_ = -118,
    /*-117 */    GN_R152A_DIFLUORETHAN = -117,
    /*-116 */    GN_1_4_DIOXAN = -116,
    /*-115 */    GN_KEROSIN = -115,
    /*-114 */    GN_METHYLAMIN = -114,
    /*-113 */    GN_SILICIUMTETRACHLORID = -113,
    /*-112 */    GN_NITROGEN_ = -112,
    /*-111 */    GN_R143A_TRIFLUORETHAN = -111,
    /*-110 */    GN_DIESEL = -110,
    /*-109 */    GN_R404A_REFRIGERANTS_MIX = -109,
    /*-108 */    GN_BROMGAS = -108,
    /*-107 */    GN_VOC = -107,
    /*-106 */    GN_PID_SENSOR = -106,
    /*-105 */    GN_R507_REFRIGERANTS_MIX = -105,
    /*-104 */    GN_ETHYLFORMIAT = -104,
    /*-103 */    GN_ARGON = -103,
    /*-102 */    GN_R113_TRICHLORFLUORETHAN = -102,
    /*-101 */    GN_HFO_1234YF_REFRIGERANT = -101,
    /*-100 */    GN_R407C_REFRIGERANTS_MIX = -100,
    /* -99 */    GN_R410A_REFRIGERANTS_MIX = -99,
    /* -98 */    GN_NITROGEN_TRIFLUORIDE = -98,
    /* -97 */    GN_PH = -97,
    /* -96 */    GN_REDOX = -96,
    /* -95 */    GN_TBM_TERT_BUTHYL_MERCAPTAN = -95,
    /* -94 */    GN_HYDROGEN_BROMIDE = -94,
    /* -93 */    GN_R438A_REFRIGERANTS_MIX = -93,
    /* -92 */    GN_R449A_REFRIGERANTS_MIX = -92,
    /* -91 */    GN_HFO_1234ZE_REFRIGERANT = -91,
    /* -90 */    GN_R448A_REFRIGERANTS_MIX = -90,
    /* -89 */    GN_C8_9_ISOPARAFFIN = -89,
    /* -88 */    GN_R454B_REFRIGERANTS_MIX = -88,
    /* -87 */    GN_R32_DIFLUOROMETHANE = -87,
    /* -86 */    GN_R513A_REFRIGERANTS_MIX = -86,
    /* -85 */    GN_R453A_REFRIGERANTS_MIX = -85,
    /* -84 */    GN_R508B_REFRIGERANTS_MIX = -84,
    /* -83 */    GN_R454C_REFRIGERANTS_MIX = -83,
    /* -82 */    GN_CHLOROTRIFLUORIDE = -82,
    /* -81 */    GN_HMDS_HEXAMETHYLDISILAZANE = -81,
    /* -80 */    GN_HYDROGEN_SELENIDE = -80,
    /* -79 */    GN_TEOS_TETRAETHOXYSILANE = -79,
    /* -78 */    GN_TMB_TRIMETHYL_BORATE = -78,
    /* -77 */    GN_GERMANIUM_TETRAFLUORIDE = -77,
    /* -76 */    GN_TUNGSTEN_HEXAFLUORIDE = -76,
    /* -75 */    GN_HEXAFLUOROBUTADIENE = -75,
    /* -74 */    GN_OCTAFLUOROCYCLOPENTENE = -74,
    /* -73 */    GN_DCS_DICHLOROSILANE = -73,
    /* -32 */    GN_PW = -32,
    /* -31 */    GN_COMMON_SIGNAL = -31,
    /* -30 */    GN_Q_FLOW_RATE = -30,
    /* -29 */    GN_PRESSURE = -29,
```

```

/* -28 */ GN_MASS = -28,
/* -27 */ GN_WIND_DIR = -27,
/* -3 */ GN_TEMPERATURE = -3,
/* -2 */ GN_AIR_VELOCITY = -2,
/* -1 */ GN_RELATIVE_HUMIDITY = -1,
/* 0 */ GN_NOTHING = 0,
/* 1 */ GN_ACETON = 1,
/* 2 */ GN_ACETONITRIL = 2,
/* 3 */ GN_ACETHYLEN = 3,
/* 4 */ GN_ACRYLNITRIL = 4,
/* 5 */ GN_AMINOPROPAN = 5,
/* 6 */ GN_AMIONIAK = 6,
/* 7 */ GN_AMYLALCOHOL = 7,
/* 8 */ GN_GASOLINE_60_95 = 8,
/* 9 */ GN_GASOLINE_80_10 = 9,
/* 10 */ GN_GASOLINE_100_140 = 10,
/* 11 */ GN_BENZOL = 11,
/* 12 */ GN_COMBUSTIBLE_GASES = 12,
/* 13 */ GN_BROMTRIFLOURMETHAN = 13,
/* 14 */ GN_1_3_BUTADIEN = 14,
/* 15 */ GN_N_BUTAN = 15,
/* 16 */ GN_I_BUTAN = 16,
/* 17 */ GN_BUTANOL = 17,
/* 18 */ GN_MEK = 18,
/* 19 */ GN_BUTYLACETAT_N = 19,
/* 20 */ GN_BUTYLACETAT_I = 20,
/* 21 */ GN_BUTYLALCOHOL = 21,
/* 22 */ GN_BUTYLEN = 22,
/* 23 */ GN_CHLOR = 23,
/* 24 */ GN_CHLORMETHAN = 24,
/* 25 */ GN_HYDROGEN_CHLORIDE = 25,
/* 26 */ GN_HYDROGEN_CYANIDE = 26,
/* 27 */ GN_CYCLOHEXAN = 27,
/* 28 */ GN_CYCLOPENTAN = 28,
/* 29 */ GN_CYCLOPROPAN = 29,
/* 30 */ GN_R12_DICHLORIDFLUORMETHAN = 30,
/* 31 */ GN_DICHLORETHAN = 31,
/* 32 */ GN_R21_DICHLORFLUORMETHAN = 32,
/* 33 */ GN_DICHLORMETHAN = 33,
/* 34 */ GN_DICHLORPROPAN = 34,
/* 35 */ GN_DIETHYLAMIN = 35,
/* 36 */ GN_DIMETHYLETHER = 36,
/* 37 */ GN_EPICHLORHYDRIN = 37,
/* 38 */ GN_NATURAL_GAS = 38,
/* 39 */ GN_ETHAN = 39,
/* 40 */ GN_ETHANOL = 40,
/* 41 */ GN_ETHYLACETAT = 41,
/* 42 */ GN_ETHYLALCOHOL = 42,
/* 43 */ GN_ETHYLEN = 43,
/* 44 */ GN_ETHYLENOXID = 44,
/* 45 */ GN_FAM_GASOLINE_65_95 = 45,
/* 46 */ GN_AVIATION_GASOLINE_40_180 = 46,
/* 47 */ GN_FORMALDEHYD = 47,
/* 48 */ GN_R22_CHLORDOFLUORMETHAN = 48,
/* 49 */ GN_HELIUM = 49,
/* 50 */ GN_HEPTAN = 50,
/* 51 */ GN_HEXAN = 51,
/* 52 */ GN_I_HEXAN = 52,
/* 53 */ GN_HEXANON = 53,
/* 54 */ GN_ISOBUTHYLACETAT = 54,
/* 55 */ GN_CARBON_DIOXIDE = 55,
/* 56 */ GN_CARBON_MONOXIDE = 56,
/* 57 */ GN_COKE_OVEN_GAS = 57,
/* 58 */ GN_AIR = 58,
/* 59 */ GN_METHAN = 59,
/* 60 */ GN_METHANOL = 60,
/* 61 */ GN_METHYLACETAT = 61,
/* 62 */ GN_METHYLALCOHOL = 62,
/* 63 */ GN_BUTYLMETHYLKETON = 63,
/* 64 */ GN_METHYLCHLORID = 64,

```



```

/* 65 */ GN_METHYLENCHLORID = 65,
/* 66 */ GN_MIBK = 66,
/* 67 */ GN_ETHYLMETHYLKETON = 67,
/* 68 */ GN_METHYLGLYKOL = 68,
/* 69 */ GN_METHYLMETHACRYLAT = 69,
/* 70 */ GN_METHYLPROPANOL = 70,
/* 71 */ GN_BROMCHLORIDFLUORMETHAN = 71,
/* 72 */ GN_N_NONAN = 72,
/* 73 */ GN_OCTAN_I = 73,
/* 74 */ GN_OKTAN = 74,
/* 75 */ GN_PENTAN_I = 75,
/* 76 */ GN_PENTAN = 76,
/* 77 */ GN_PENTANON = 77,
/* 78 */ GN_PENTEN = 78,
/* 79 */ GN_PENTYLACETAT = 79,
/* 80 */ GN_PERCHLORETHYLEN = 80,
/* 81 */ GN_PROPAN = 81,
/* 82 */ GN_PROPANOL = 82,
/* 83 */ GN_PROPYLACETAT_I = 83,
/* 84 */ GN_PROPYLACETAT_N = 84,
/* 85 */ GN_PROPYLALCOHOL_N = 85,
/* 86 */ GN_PROPYLALCOHOL_I = 86,
/* 87 */ GN_PROPEN = 87,
/* 88 */ GN_PROPYLENDICHLORID = 88,
/* 89 */ GN_OXYGEN = 89,
/* 90 */ GN_SULPHUR_DIOXIDE = 90,
/* 91 */ GN_SULPHUR_HEXAFLUORIDE = 91,
/* 92 */ GN_HYDROGEN_SULPHIDE = 92,
/* 93 */ GN_TOWN_GAS = 93,
/* 94 */ GN_NITROGEN_DIOXIDE = 94,
/* 95 */ GN_NITROGEN_MONOXIDE = 95,
/* 96 */ GN_STYROL = 96,
/* 97 */ GN_TETRACHLORETHAN = 97,
/* 98 */ GN_TULUOL = 98,
/* 99 */ GN_TRICHLORETHAN = 99,
/* 100 */ GN_TRICHLORETHYLEN = 100,
/* 101 */ GN_R23_TRIFLUORMETHAN = 101,
/* 102 */ GN_VINYLCETAT = 102,
/* 103 */ GN_VINYLCHLORID = 103,
/* 104 */ GN_HYDROGEN = 104,
/* 105 */ GN_WATER_GAS = 105,
/* 106 */ GN_XYLOL = 106,
/* 107 */ GN_OZON = 107,
/* 108 */ GN_PHOSGEN = 108,
/* 109 */ GN_PHOSPHIN = 109,
/* 110 */ GN_SILAN = 110,
/* 111 */ GN_ARSIN = 111,
/* 112 */ GN_CHLORDIOXID = 112,
/* 113 */ GN_DIBORAN = 113,
/* 114 */ GN_R123_DICHLORTRIFLUORETHAN = 114,
/* 115 */ GN_DIETHYLETER = 115,
/* 116 */ GN_NITROUS_OXIDE = 116,
/* 117 */ GN_ETHANE_ACID = 117,
/* 118 */ GN_FLUOR = 118,
/* 119 */ GN_HYDROGEN_FLUORIDE = 119,
/* 120 */ GN_GERMANIUM_HYDROGEN = 120,
/* 121 */ GN_HYDRAZIN = 121,
/* 122 */ GN_PHENOL = 122,
/* 123 */ GN_PROPYLENOXID = 123,
/* 124 */ GN_R134A_TETRAFLUORETHAN = 124,
/* 125 */ GN_THT = 125,
/* 126 */ GN_TOX_ALERT = 126,
/* 127 */ GN_R365_PENTAFLOURBUTAN = 127
} gas_names_t;

```


4.2 Enumeration units_t

```
typedef enum unit_t {  
    /* 0 */    UN_NOTHING = 0,  
    /* 1 */    UN_PARTS_PER_MILLION = 1,  
    /* 2 */    UN_PERCENT_BY_VOLUME = 2,  
    /* 3 */    UN_PERCENT_LOWER_EXPL_LIMIT = 3,  
    /* 4 */    UN_PARTS_PER_BILLION = 4,  
    /* 5 */    UN_MICRO_GRAM = 5,  
    /* 6 */    UN_MILLI_GRAM = 6,  
    /* 7 */    UN_PERCENT = 7,  
    /* 8 */    UN_PROMILL = 8,  
    /* 9 */    UN_METER_PER_SECOND = 9,  
    /* 10 */    UN_DEGREE_CELSIUS = 10,  
    /* 11 */    UN_MILLI_VOLT = 11,  
    /* 12 */    UN_VOLT = 12,  
    /* 13 */    UN_MILLI_AMPERE = 13,  
    /* 14 */    UN_AMPERE = 14,  
    /* 15 */    UN_OHM = 15,  
    /* 16 */    UN_DIGIT = 16,  
    /* 23 */    UN_GRAD = 23,  
    /* 24 */    UN_DEGREE_FAHRENHEIT = 24,  
    /* 25 */    UN_GRAM = 25,  
    /* 26 */    UN_KILO_GRAM = 26,  
    /* 27 */    UN_PASCAL = 27,  
    /* 28 */    UN_KILO_PASCALA = 28,  
    /* 29 */    UN_BAR = 29,  
    /* 30 */    UN_PSI = 30,  
    /* 31 */    UN_SECOND = 31,  
    /* 32 */    UN_MINUTE = 32,  
    /* 33 */    UN_KILO_BYTE = 33,  
    /* 34 */    UN_MEGA_BYTE = 34,  
    /* 35 */    UN_GIGA_BYTE = 35,  
    /* 36 */    UN_MILLI_GRAM_PER_LITRE = 36,  
    /* 37 */    UN_STANDARD_LITER_PER_MINUTE = 37,  
    /* 38 */    UN_MICRO_AMPERE = 38,  
    /* 39 */    UN_WATT = 39,  
    /* 40 */    UN_GRAM_PER_CUBIC_METRE = 40,  
    /* -1 */    UN_NUL = -1  
} unit_t;
```

GfG Instrumentation, Inc.

1194 Oak Valley Dr. Ste. 20, Ann Arbor, MI 48108

Phone: 800-959-0329

Fax: 734-769-1888

Email: info@goodforgas.com



GfGsafety.com/us-en

As of: January 16, 2024 Subject to change